


SHIMANO

TRINIDAD A-RB

TN-40



Part No.	Description	Part No.	Description	Part No.	Description
TGT0058	Spacer "B"	TGT0424	Handle Nut Plate	TGT0463	"BR" Gear (A)
TGT0062	Click Pawl Retainer	TGT0425	Handle Nut	TGT0464	Click Gear Retainer
TGT0065	Spacer (A)	TGT0427	Drive Shaft Shield	TGT0465	Bearing Retainer
TGT0111	Drive Shaft Retainer	TGT0428	Star Drag	TGT0467	"BR" Set Plate
TGT0128	Handle Nut Plate Screw	TGT0429	Star Drag Washer	TGT0468	Left Side Plate
TGT0182	Cast Control Spacer (A)	TGT0430	Drag Spring Washer (10L)	TGT0470	"BR" Bushing
TGT0277	Cast Control Spacer (B)	TGT0433	Bearing Seal	TGT0471	"BR" Dial
TGT0279	Smoother	TGT0435	"BR" Set Plate Screw	TGT0472	Click Button
TGT0282	Eccentric Cam Bushing	TGT0436	Right Side Plate	TGT0481	Bearing Thrust Washer
TGT0283	Clutch Spring	TGT0437	Cast Control Cap	TGT0486	Ball Bearing
TGT0284	Clutch Cam	TGT0438	"O" Ring	TGT0493	Roller Clutch Bearing
TGT0285	Clutch Lever Screw	TGT0439	Clutch Lever	TGT0494	Roller Clutch Inner Tube
TGT0295	Click Pin	TGT0440	Line Clip	TGT0499	Ball Bearing
TGT0296	Click Spring	TGT0441	Key Washer	TGT0500	Ball Bearing
TGT0303	Anti-Reverse Pawl	TGT0442	Drag Washer (D)	TGT0501	Handle Assembly
TGT0305	Multi-Purpose Screw	TGT0443	Eared Washer (E)	TGT0502	Spool Assembly
TGT0319	"BR" Cam Pin	TGT0444	Key Washer (C)	TGT0589	Click Pawl Spring
TGT0320	"BR" Cam	TGT0445	Drag Washer (B)	TGT0590	Click Pawl
TGT0321	"BR" Friction Washer	TGT0446	Drive Gear	TGT0591	Click Spring
TGT0322	"BR" Washer (C)	TGT0447	Drag Washer (A)	TGT0740	Drag Washer (F)
TGT0323	"BR" Washer (A)	TGT0448	Anti-Reverse Ratchet	TGT0741	Drive Shaft
TGT0324	"BR" Gear (C)	TGT0450	Yoke Spring	TGT0761	Right Side Plate Screw (C)
TGT0325	"BR" Washer (B)	TGT0451	Yoke	TGT0766	Right Side Plate Screw (A)
TGT0329	Spacer (B)	TGT0452	Pinion Gear	TGT0768	Side Plate Screw
TGT0331	Click Pawl Spacer	TGT0453	Yoke Plate		
TGT0332	Click Spring Retainer	TGT0454	Set Plate Screw (B)		
TGT0334	Click Spring Holder	TGT0455	Anti-Reverse Pawl Keeper	TGT0351	Rod Clamp Bolt (accessory)
TGT0335	"BR" Click Spring	TGT0456	Set Plate	TGT0352	Rod Clamp Nut (B) (accessory)
TGT0336	"BR" Click Pin	TGT0457	Set Plate Screw (A)	TGT0353	Rod Clamp (accessory)
TGT0338	"BR" Washer (D)	TGT0459	Drive Shaft Washer (A)	TGT0354	Rod Clamp Nut (A) (accessory)
TGT0348	Spacer (C)	TGT0460	One-Piece Frame		
TGT0360	Drive Shaft Washer (B)	TGT0462	Click Gear	TGT0476	Wrench (accessory)